

1. MEASURE THE DOOR FRAME

WHERE YOU WANT THE TOP
ROD TO HANG FROM

PANELS SHOULD BE JUST
ABOVE THE FLOOR

2. LAY THE PANELS ON THE FLOOR AND MARK
THE REQUIRED DOOR HEIGHT ON THEM WITH TAPE

3. TO STOP THE PANELS MOVING WEIGH THEM
DOWN WITH FOR INSTANCE A BOOK...

4. SPLIT THE TOP ROD TAKE THE THIN COVER OFF
AND LAY THE PANELS OVER THE THICKER CHANNEL
SECTION USE THE TAPE MARKERS TO POSITION.
OVERLAP AS REQUIRED.

5. LAY THE THIN COVER OVER THE PANELS AND USE
A Mallet TO PIN THE TOP ROD COVER IN PLACE
AND SECURE THE PANELS IN PLACE

6. HOLD UP THE SCREEN TO THE
DOORWAY TO CHECK HOW THE
PANELS OVERLAP AND ARE
LEVEL THEN FIX IN POSITION
WITH HOOK AND LOOP TAPE OR
SUPPLIED SCREWS

CUT OFF EXCESS PANELS FROM
THE TOP ONLY WHEN YOU ARE
HAPPY

JOINING 2 RODS TOGETHER

SECURE THE MATERIAL, SCREEN IN THE USUAL WAY.

OVERLAP THE JOIN WITH THE THIN COVER

PUT HOOK AND LOOP TAPE ON THE BACK OR DRILL THROUGH TO ATTACH TO DOOR FRAME