

## Magnetic Patio Door

1. Make sure the door frame is clean. Measure your doorway, if the screen is too large it can be cut to size. Please note that if you cut the screen you will lose the edging and it will need to be hemmed. You can make the screen shorter by folding it over or clamping it further up the top rod. Avoid cutting the join at the top which helps the screen to overlap.
2. The material can be ironed, make sure the iron is set on warm and that some material is laid between the iron and magnetic screen.
3. Trap the screen in the top rod and attach to the door frame with the hook and loop tape, or screws (drill through the ridges).
4. Attach the sides of the screen to the door frame with hook and loop tape.

