



THE 3M COMMAND STRIPS PUT THEM TOGETHER



PRESS THE ENTIRE STRIP TOGETHER UNTIL THEY 'CLICK'



PEEL OFF THE ADHESIVE STRIP



PUT ON THE TOP OF THE ROD



PEEL OFF THE ADHESIVE STRIP



PRESS INTO POSITION ON THE DOOR FRAME FOR 30 SECONDS



TO USE THE SCREWS, DRILL THROUGH THE RIDGES



USE A 5MM DRILL



PUSH THROUGH THE SCREW AND COVER